


Emergency Break Glass Parts



EB-20 (Glass)

How do you reset the emergency brake glass?

When you push the key up that will release this phase plate that will come down cause for an inch. Take the key back out. And push the glass back up that has reset your coal point.

Specifications

S4A Model No.	EB-20(Glass)	Product weight	10g
Scope of application	Suitable for emergency alarm glass breaking switch	Dimensions	74x40x1(mm)

Dimensions

